



PN08

1. PN08




2.




3. GSMDL





GSDML-V2.32-Huceen-PN08_V0.1-20200330



PROFI NET

4. PROFI NET







5. PROFI NET



PLC



IP

PLC




s7-200_SMART_system_manual_zh-CHS





6.



AM06 PN

128

I W128

I 128. 0

地址	格式	当前值	新值
1	QW128		
2	QW132		
3	QW132		
4	QW134		
5	IW128		

7.



1.

-- 2 LED

1. RUN --

2. STOP --

3. ERROR --

--

(CPU)

1. --

2. --

2 ()

-- 2 LED

--

--

--

V2.0